#### **CLIPPER AND BLADE CARE TIPS**

## Tips to keep your equipment in great shape!

- Review the Use & Care instructions provided with your tool, as each one requires unique attention.
- Wash and dry the animal prior to clipping to extend the life of the clipper and blade as well as improve performance.
- Clean the blade and under the drive cap by using a soft brush (or old toothbrush) to remove hair and debris from hard-to-reach spaces.
- Disinfect blades with Cool Care Plus®. Review the instructions on the can for proper usage. Ensure that blade surfaces are wet for 10 minutes to kill germs and viruses.
- Oil your blades using the 5-point oiling system.
  With the blade pointed down, use 3 drops across the teeth and 1 drop on each back rail. Wipe excess oil using a clean, soft cloth.
- If you notice streaks or dragging, it may be time to change the clipper blade drive.
- Keep your cord well cared for by wrapping it loosely during storage. Avoid tangles by keeping the cord straight.

#### LIVESTOCK BLADES

The sharp tips on livestock blades are for skimming and sculpting the hair—never for clipping down to the skin. The Blue Ribbon® II Blocking Blade has especially sharp teeth so that it can cut through adhesives and show day hair products.







#### **WORK SMARTER, NOT HARDER.**

### Using the Pulse Li 5 Clipper for Equine Grooming

The Pulse Li 5 Clipper is extremely quiet, making it perfect for grooming ears, muzzle, bridle path and fetlocks. It features a 5-position blade that can be adjusted to cut lengths between 40 and 9, allowing for grooming versatility. Additionally, it features a lithium-ion battery that lasts up to 2 hours for nonstop, cordless clipping.





### SHOW EDGE®

By pairing our extra-wide, Show Edge® livestock blades with your detachable blade clipper, you get the benefits of the wider cut found on heavy-duty shears but at a fraction of the weight.



mpany Form# 101067 Rev. E

# LIVESTOCK & EQUINE GROOMING GUIDE

andis













# LIVESTOCK & EQUINE GROOMING GUIDE Use the chart below to determine which Andis® blade is the best choice for clipping your animals.

	Beef Cattle	Dairy Cattle	Dairy Goats	Meat Goats (Doe)	Meat Goats (Wether)	Lamb/Sheep	Hog	Equine
Show Edge Surgical #40110	ול־וֹנ	Body, Udder	Body, Udder	ור וו	) - /	Body	-11-1/	Surgical Sites/Wounds
Show Edge® Medium #40165	Body, Face, Tail	Body, Face, Tail	Body, Face, Legs	Face, Neck	Body, Ears, Face	Ears, Face	Body, Face	Body
Show Edge® General #40175	Body, Face, Tail	Body, Face, Tail	Body, Face, Tail	Face, Tail	Body, Ears, Face	Body, Ears, Face		Body (cold climates)
Blue Ribbon° II Blocking #62135	Body, Legs, Shoulder			Body, Legs	Legs	Legs		
Super Blocking #64340	Body, Legs, Shoulder			Body, Legs, Horns	Legs	Legs		
Medium Blending #64330	Face Back Dragging, Legs, Neck, Shoulder, Tail, Sheath, Navel	Body	Body, Face, Tail	Body, Face, Tail Back Dragging, Horns	Body, Face, Legs, Tail	Face, Head, Legs		
<b>T-84</b> #21641	Face, Neck, Tail	Body	Body, Ears, Face	Belly, Ears, Face, Neck	Body	Ears, Face		Body, Ears, Face Legs
T-10 #22305		Body, Udder	Body, Ears, Face	Ears, Face, Neck, Chest				Body, Ears, Face Legs
<b>3/4 HT</b> #63980	Neck, Shoulder			Body			Body	Body (cold climates)
<b>5/8 HT</b> #64930	Neck, Shoulder		Body	Neck, Shoulder, Head			Body	Body (cold climates)
<b>9/10</b> #64120, #64071			Ears	Tail			Body (with attachment combs)	Ears, Whiskers, Fetlocks, Bridle Path, Legs
<b>40/50SS</b> #64076, #64185		Legs, Tail, Udder	Ears	Udder				Surgical Sites/Wounds, Ears, Whiskers, Bridle Path
<b>4FC/5FC/7FC</b> #64123, #64370, #64121				Body, Neck	Body			Whiskers, Ears, Legs, Body